



**PRO-FLO XT INTAKE MANIFOLD**  
**For Big Block Chevy Rectangle Port Engines**  
**Part #7136 & #71363**  
**INSTALLATION INSTRUCTIONS**

**PLEASE** study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

**IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void your warranty and may result in poor performance and engine or vehicle damage.**

**DESCRIPTION:** The Edelbrock Pro-Flo XT intake manifold is designed to allow the use of electronic direct port fuel injection on standard deck height big block Chevy engines equipped with rectangle port cylinder heads. The height of the manifold from the end seal is 10" at the front and 9.8" at the rear. This intake manifold features a log style plenum and large free-flowing tunnel ram style runners. The throttle body flange is machined to accept either an LS style 90mm throttle body (such as our 90mm XT; PN 3869); or a Ford 5.0L style 90mm throttle body (such as our PN 3818). A provision for installing an LS1-style MAP sensor has been drilled and a separate mounting bracket is supplied.

**ACCESSORIES & INSTALLATION ITEMS:** Major recommendations are listed below. See our catalog for details. **To order a catalog, call (800) FUN-TEAM**, or visit [www.edelbrock.com](http://www.edelbrock.com).


- **EGR SYSTEMS:** Intake manifold will not accept stock EGR (Exhaust Gas Recirculation) equipment. EGR systems are used on most 1972 and later model vehicles. Check local laws for requirements.
- **ENGINE MANAGEMENT:** This manifold was developed for use with the Pro-Flo XT EFI management system, part #3558. If this manifold is being used separately, it will require several additional components such as a throttle body and ECU, as well as sensors, injectors and rails before the installation can be completed. Although Edelbrock offers these components separately, compatibility with your EFI system must be confirmed prior to purchasing and installing them.
- **MANIFOLD AIR PRESSURE SENSOR:** A bracket for mounting an LS1 style MAP sensor is included with this manifold. This sensor is sold separately as part #36019, but compatibility with your engine management system must be verified prior to purchase.
- **THROTTLE BODY RECOMMENDATIONS:** This manifold has been designed for use with a 90mm throttle body, such as the Pro-Flo XT throttle body, part #3869 (LS) or part #3818 (Ford). Larger bores can be accommodated with additional machining. Care must be taken when selecting a throttle body as a larger orifice will increase pedal sensitivity.
- **WATER OUTLET:** Due to the limited clearance below the throttle body flange, a low profile thermostat housing must be used such as GM P/N: 12342024 (Chrome) or Trans-Dapt P/N: 9229.
- **THROTTLE BRACKETS:** A universal throttle cable bracket has been supplied with this intake manifold. It will work with most OEM cables using a square clip retention system or Lokar cables utilizing 5/16" holes, but some applications will require modification or substitution for proper operation. This manifold is not compatible with throttle rods and such systems should be converted to cable operation.
- **FUEL RAILS:** The Big Block Chevy Pro-Flo XT Fuel Rail Kit has been designed for use with this manifold and is available as part #3658. This kit will allow the use of either Pico or standard height fuel injectors and is tapped for -8 AN fittings on all four ends.
- **GASKETS:** We recommend the use of Edelbrock intake gasket #7202 with this intake manifold. Do not use competition-style intake gaskets for this street manifold. Due to material deterioration over time, internal leakage of vacuum, oil, and/or coolant may occur.
- **CAMSHAFT AND HEADERS:** Pro-Flo XT series manifolds are compatible with aftermarket camshafts and headers designed to work anywhere within the 1500-7000 rpm range.

## INSTALLATION PROCEDURE

1. Use only recommended intake gaskets set when installing this intake manifold.
2. Fully clean the cylinder head intake flanges and the engine block end seal surfaces prior to applying gaskets.
3. Apply Edelbrock Gasegacinch sealant P/N 9300 to both cylinder head flanges and to the cylinder head side of the gaskets, allow them to air dry, then attach the intake gaskets.
4. Do not use cork or rubber end seals. Use RTV silicone sealer instead. Apply a ¼" high bead across each block end seal surface, overlapping the intake gasket at the four corners. This method will eliminate end seal slippage.
5. Install the intake manifold and hold-down bolts, following the torque sequence shown below.

**Big Block Chevy Torque Sequence**  
**Torque remaining bolts to 25 ft/lbs.**  
**Firing Order: 1-8-4-3-6-5-7-2**

**Turn Distributor Counter-Clockwise to Advance Ignition Timing**



**Edelbrock LLC • 2700 California St. • Torrance, CA 90503**  
**Sales Line: 310-781-2222 • Tech Line: 800-416-8628**